

ARRI WHITE RADIO		FREQ (MHz)	WIFI 2.4 CHANNELS			
	<b>0</b> (2,410)	2,407	<b>1</b> (2,412)	<b>2</b> (2,417)	<b>3</b> (2,422)	<b>4</b> (2,427)
		2,408				
<b>1</b> (2,415)		2,409	<b>6</b> (2,437)	<b>7</b> (2,442)	<b>8</b> (2,447)	<b>9</b> (2,452)
		<b>2,410</b>				
	<b>8</b> (2,420)	2,411	<b>11</b> (2,462)	<b>12</b> (2,467)	<b>13</b> (2,472)	<b>10</b> (2,457)
		2,412				
		2,413	<b>12</b> (2,467)	<b>13</b> (2,472)	<b>14</b> (2,284)	
		2,414				
<b>9</b> (2,425)		<b>2,415</b>				
		2,416				
	<b>2</b> (2,430)	2,417				
		2,418				
		2,419				
		<b>2,420</b>				
		2,421				
		2,422				
		2,423				
		2,424				
<b>3</b> (2,435)		<b>2,425</b>				
		2,426				
	<b>10</b> (2,440)	2,427				
		2,428				
		2,429				
		<b>2,430</b>				
		2,431				
		2,432				
		2,433				
		2,434				
<b>11</b> (2,445)		<b>2,435</b>				
		2,436				
	<b>4</b> (2,450)	2,437				
		2,438				
		2,439				
		<b>2,440</b>				
		2,441				
		2,442				
		2,443				
		2,444				
<b>5</b> (2,455)		<b>2,445</b>				
		2,446				
	<b>12</b> (2,460)	2,447				
		2,448				
		2,449				
		<b>2,450</b>				
		2,451				
		2,452				
		2,453				
		2,454				
<b>13</b> (2,465)		<b>2,455</b>				
		2,456				
	<b>6</b> (2,470)	2,457				
		2,458				
		2,459				
		<b>2,460</b>				
		2,461				
		2,462				
		2,463				
		2,464				
<b>7</b> (2,475)		<b>2,465</b>				
		2,466				
		2,467				
		2,468				
		2,469				
		<b>2,470</b>				
		2,471				
		2,472				
		2,473				
		2,474				
		<b>2,475</b>				
		2,476				
		2,477				
		2,478				
		2,479				
		2,480				
		2,481				
		2,482				
		2,483				
		2,484				